



Installation Instructions for Mincey Marble's Shower Nook

Product number: AN-08



MATERIALS NEEDED:

- Torpedo level
- Silicone (100%) and caulk gun
- Hot glue gun and commercial grade glue sticks
- Acetone
- Clean, dry rags
- Pencil

Two types of adhesive are needed to install the shower nook because they serve different purposes. The hot melt glue bonds immediately, but will not hold the nook for more than a few days. The silicone takes a few hours to cure, but after curing, it will secure the nook indefinitely.

After determining the location of the nook, make your marks on the sheetrock wall. Make sure to lay out level and plumb lines on your sheet rock wall. Check that there are no studs or blocking in the wall by cutting out the sheetrock in the area where the nook is going. Also, be careful if using a keyhole saw so as not to cut through the wall in the room behind the wall you are working on. The size of this hole will be about 1" smaller than the outside dimensions of the nook. The hole in the panel should only be cut after the sheetrock has been cut to ensure there are no obstructions in the way of the nook.

When ready to install the nook, clean the back of the edges of the nook with a clean rag and acetone. Using the torpedo level, hold the nook in the hole and level the nook. Make a mark on the panel with your pencil for a reference line to be used during installation. Use a combination of a few daubs of silicone and hot melt glue to adhere the nook to the panel. Once the hot melt glue has been applied, immediately install the nook, using the reference lines on the wall to keep the nook level. Clean the pencil marks you made earlier with acetone. Then silicone around the edge of the nook in color-matching 100% silicone.