

AN-06, AN-07 & AN-09 Accessories Niches Installation Instructions



AN-06 - Accessories Niche



AN-07 - Accessories Niche



AN-09 - Accessories Niche

Tools and Materials needed:

1. Torpedo Level
2. Silicone (100%) and Caulk Gun
3. Hot Glue Gun and Commercial Grade Glue Sticks
4. Acetone
5. Clean Dry Rags
6. Pencil

Two types of adhesive are needed to install the accessory niches because they serve different purposes. The hot melt glue bonds immediately, but will not hold the soap dish for more than a few days. The silicone takes a few hours to cure, but after curing, it will secure the soap dish indefinitely.

After determining the location of the niche/nook, make your marks on the sheet rock wall. Make sure to lay out level and plumb lines on your sheet rock wall. Make sure that there are no studs or blocking in the wall by cutting out the sheet rock in the area where the niche/nook is going. Also, be careful if using a keyhole saw so as not to cut through the wall in the room behind the wall you are working on. The size of this hole will be about 1" smaller than the outside dimensions of the niche/nook. The hole in the panel should only be cut after the sheet rock has been cut to ensure there are no obstructions in the way of the niche/nook. When ready to install the niche/nook, clean the back of the edges of the niche/nook with a clean rag and acetone. Using the torpedo level, hold the niche/nook in the hole and level the niche/nook. Make a mark on the panel with your pencil for a reference line to be used during installation. Use a combination of a few daubs of silicone and hot melt glue to adhere the niche/nook to the panel. Once the hot melt glue has been applied, immediately install the accessory niche, using the reference lines on the wall to keep the niche/nook level. Clean the pencil marks, you made earlier, with acetone. Then silicone around the edge of the niche/nook in color matching 100% silicone.

For questions, please call Mincey Customer Service at 770.532.0451